

NEUSPEED®

30mm FRONT ANTI-ROLL BAR 2000-up HONDA S2000 PART # 15.20.30 INSTALLATION INSTRUCTIONS

PARTS LIST:

1 – ANTI-ROLL BAR
2 – BUSHINGS

1 – PKG. SILICONE GREASE

TOOLS REQUIRED:

1 – RATCHET
1 – 3” EXTENSION
1 – 10mm SOCKET
1 – 14mm SOCKET

1 – 14mm WRENCH
1 – 5mm HEX WRENCH
1 – TORQUE WRENCH



1. Park car on a flat, level surface capable of supporting the vehicle's weight on jack and jack stands.

2. Using the manufacturers recommended lifting point(s), raise front of vehicle and support with jack stands. **NEVER WORK ON A VEHICLE SUPPORTED ONLY WITH A JACK!**



4. Remove two (2) fasteners (10mm Hex) securing left and right corners of lower panel.



3. Remove plastic push fasteners (7) securing lower panel.



5. Disconnect end links from anti-roll bar by securing stud with 5mm hex key and loosening nut with 14mm wrench. (Left side shown, repeat for right side.)



6. Remove four (4) bolts (14mm Hex) securing anti-roll bar and remove bar from vehicle. (Left side shown, repeat for right side)



8. Position bar on end links and install nuts. Torque to 38Nm (28 lbf ft.) (Left side shown, repeat for right side)



7. Using supplied grease, lube inner surface of bushing and install on bar. (Left side shown, repeat for right side)



9. Install bracket over bushing and torque fasteners to 45 Nm (33 lbf ft.) (Left side shown, repeat for right side)

10. Replace lower panel in reverse of removal.

11. Installation is now complete.

12. Double-check complete installation and make sure the new anti-roll bar does not interfere with other components. TEST DRIVE CAREFULLY!