

# NEUSPEED®

## 25mm RACE SERIES TUBULAR REAR ANTI-ROLL BAR

FITS 2006-up AUDI A3 (8P) FWD

2005-up VOLKSWAGEN GTI MKV, JETTA V,

2006-up PASSAT B6 FWD & 2006-up RABBIT

PART # 25.02.25.3

INSTALLATION INSTRUCTIONS

**PARTS LIST:** 1 – TUBULAR ANTI-ROLL BAR 1 – PKG. SILICONE GREASE  
2 – POLYURETHANE BUSHINGS

**TOOLS REQUIRED:** 1 – RATCHET  
1 – M10 TRIPLE SQUARE (12 POINT) OR 8mm HEX KEY WRENCH  
1 – M6 TRIPLE SQUARE (12 POINT) OR 5mm HEX KEY WRENCH  
1 – 16mm WRENCH

1. Park car on a flat, level surface capable of supporting the vehicle's weight on jack and jack stands. Using the manufacturer's recommended lifting point(s), raise rear of vehicle and support with jack stands. **NEVER WORK ON A VEHICLE SUPPORTED ONLY WITH A JACK!**

2. Disconnect end-links from original anti-roll bar by securing stud with M6 Triple Square or 5mm hex key wrench and loosening nut with 16mm wrench.

3. Remove four bushing clamp mounting bolts using a M10 Triple Square or 8mm hex key wrench and remove original anti-roll bar from vehicle.



4. Apply silicone grease to the inside of supplied bushings and install on the inside of stop washer on *NEUSPEED* anti-roll bar.



5. Install *NEUSPEED* anti-roll bar using original clamps and bolts to sub-frame. Torque bolts to 20Nm (15 ft-lbs).



6. Attach end-links to *NEUSPEED* anti-roll bar using original nuts. Torque to 40Nm (30 ft-lbs). Forward hole is softer setting; rearward hole is stiffer setting (more oversteer).

7. Double check complete installation and TEST DRIVE CAREFULLY!