

NEUSPEED®

19mm REAR ANTI-ROLL BAR

2003-up HONDA ACCORD & 2004-up Acura TSX

PART # 25.20.19.3 & 25.20.19.4

INSTALLATION INSTRUCTIONS

PARTS LIST:

1 – ANTI-ROLL BAR	1 – PKG. SILICONE GREASE
2 – BUSHINGS	4 – WASHER
2 – BUSHING CLAMPS	2 – M10x1.25 NYLOCK NUTS
4 – M8x20mm HEX BOLTS	

TOOLS REQUIRED:

1 – 5MM HEX KEY WRENCH	1 – 14mm WRENCH
1 – 12mm SOCKET	1 – 17mm WRENCH

Raise vehicle and support with jack stands under lifting points. **NEVER WORK UNDER A VEHICLE SUPPORTED ONLY WITH A JACK!** Spray all end link threads at sway bar with WD40 or equivalent.

1. Remove sway bar end link nuts (14mm). Use a 5mm hex key wrench on end of the threads to keep ball joint from spinning.
2. Unbolt sway bar bushing clamps (12mm), and remove sway bar.
3. Coat the inside of the polyurethane bushing with special *NEUSPEED* grease supplied, and install one on each side of straight section just before the first 90° bend. Mount sway bar with new bushings, clamps, bolts, and washers supplied.
4. Carefully double-check complete installation, and tightness of **ALL** nuts and bolts. **TEST DRIVE CAREFULLY!**