

NEUSPEED®

UPPER STRUT TIE BAR FOR 2002 ACURA RSX TYPE-S

PART # 35.20.47 & 35.20.47P
INSTALLATION INSTRUCTIONS

PARTS LIST: 1 – UPPER STRUT TIE BAR 4 – CAPS

TOOLS REQUIRED: 1 – RATCHET 1 – PLIERS
1 – 14mm DEEP SOCKET

1. Before installing your *NEUSPEED* Upper Strut Tie-Bar, park vehicle on a flat level surface.



2. Remove cruise control cable from mounting bracket and bend the front of the cruise control bracket back (towards rear of car) about $\frac{1}{8}$ " to $\frac{1}{4}$ " using a pair of pliers.



3. Remove two outer nuts (14mm Hex) from left and right strut towers.



4. Slip front leg of *NEUSPEED* Upper Strut Tie-Bar under cruise control cable (as shown) and over studs on passenger side strut tower. Check for clearance between bracket and strut bar. If strut bar contacts bracket, repeat step two until clearance is sufficient. Align bar over studs on driver side tower and push down firmly.



5. Start each retaining nut by hand, then torque to 33 ft. lbs.



6. Install caps on strut bar ends and secure cruise control cable to bracket.



7. Installation complete

8. Double-check complete installation and TEST DRIVE CAREFULLY!