

# NEUSPEED®

## UPPER STRUT TIE BAR FOR 2003-up HONDA ACCORD 4-cyl. & V6

PART # 35.20.58 & 35.20.58P  
INSTALLATION INSTRUCTIONS

**PARTS LIST:** 1 – UPPER STRUT TIE BAR 4 – CAPS

**TOOLS REQUIRED:** 1 – RATCHET 1 – 14mm SOCKET 1 – 3” EXTENSION



1. Before installing your *NEUSPEED* Upper Strut Tie-Bar, park vehicle on a flat level surface. Remove two outer nuts (14mm Hex) from left and right strut towers.



3. Install caps on strut bar ends as shown



2. Position *NEUSPEED* Upper Strut Tie-Bar over studs on passenger side strut tower and push down firmly. Align bar over studs on driver side tower and push down firmly. Start each retaining nut by hand, then torque to 33 ft. lbs.



4. Installation complete.

5. Double-check complete installation and **TEST DRIVE CAREFULLY!**

©Copyright 2003, *NEUSPEED*®. All rights reserved. Reproduction in whole or in part prohibited.  
DOC.35.20.58(P) Rev. 03.27.03

**NEUSPEED** • 3300 Corte Malpaso • Camarillo, CA 93012 • 805.388.7171 • 805.388.0030 FAX  
Visit us on the web...<http://www.neuspeed.com> & <http://www.apsoutlet.com>