

NEUSPEED®

UPPER STRUT TIE BAR FOR 2002 HONDA CIVIC Si

PART # 35.20.79 & 35.20.79P
INSTALLATION INSTRUCTIONS

PARTS LIST: 1 – UPPER STRUT TIE BAR 4 – CAPS

TOOLS REQUIRED: 1 – RATCHET 1 – 14mm SOCKET
1 – 10mm WRENCH OR SOCKET 1 – 14mm DEEP SOCKET



1. With vehicle at rest and all four wheels on level ground, remove two outer nuts (14mm Hex) from left strut tower and two inner nuts from right strut tower.



2. Remove bolt (10mm Hex) securing A/C Condenser line.



3. Slip rear leg of *NEUSPEED* Upper Strut Tie-Bar under A/C condenser line (as shown) and over studs on passenger side strut tower. Align bar over studs on driver side tower and push down firmly. Install bolt for A/C Condenser line bracket and torque to 5 Ft. Lbs.



6. Install caps on strut bar ends.



4. Start each retaining nut by hand, then torque to 33 ft. lbs. Note: Install rear driver side nut by hand with 14mm deep socket then torque to 33 ft.lbs. with standard socket.



6. Installation complete

7. Double-check complete installation and TEST DRIVE CAREFULLY!