

NEUSPEED®

LOWER TIE BAR FOR 2002-UP ACURA RSX TYPE-S

PART #45.20.48P

INSTALLATION INSTRUCTIONS

Parts List: 1 – Lower Tie Bar
4 – M8 x 16mm Hex Cap Bolts

Tools Required: 1 – 12mm Wrench
1 – 5mm Hex Key Wrench



1. Remove four 8mm (12mm hex) bolts securing OE brace to sub-frame and remove brace.



2. Position NEUSPEED brace with name facing rear and hand tighten four supplied M8 x 16mm stainless steel cap bolts (5mm hex key wrench), then torque to 18ft./lb.

©Copyright 2002, NEUSPEED®. All rights reserved. Reproduction in whole or in part prohibited.

NEUSPEED • 3300 Corte Malpaso • Camarillo, CA 93012 • 805.388.7171 • FAX 805.388.0030
Visit us on the web...<http://www.neuspeed.com> & <http://www.apsoutlet.com>