

NEUSPEED®

FRONT LOWER X-BRACE FOR HONDA S2000 2000-UP

PART # 45.20.67

INSTALLATION INSTRUCTIONS

PARTS LIST: 1 – X-BRACE 4 – M10 X 40 SOCKET HEAD BOLTS

TOOLS REQUIRED: 1 – RATCHET 1 – 8mm HEX DRIVER
1 – 14mm SOCKET 1 – TORQUE WRENCH

1. Park car on a flat, level surface capable of supporting the vehicle's weight on jack and jack stands.

2. Using the manufacturers recommended lifting point(s), raise front of vehicle and support with jack stands. **NEVER WORK ON A VEHICLE SUPPORTED ONLY WITH A JACK!**



3. Remove (4) bolts (14mm hex) in area shown.



4. Position brace as shown and install supplied bolts using 8mm hex driver. After each bolt is installed hand tight, torque all bolts to 50 ft./lbs. (68Nm)

5. TEST DRIVE CAREFULLY!

NOTE: DO NOT USE X-BRACE AS A JACKING POINT!