

NEUSPEED®

FRONT LOWER X-BRACE FOR '01 AND UP ACURA RSX, '02 AND UP HONDA CIVIC Si PART # 45.20.68 INSTALLATION INSTRUCTIONS

PARTS LIST: 1 – X-BRACE

TOOLS REQUIRED: 1 – FLOOR JACK OR LIFT
1 – JACK STANDS OR JACK SCREW
1 – RATCHET
1 – 17mm DEEP SOCKET
1 – 19mm DEEP SOCKET
1 – TORQUE WRENCH

1. Park car on a flat, level surface capable of supporting the vehicle's weight on jack and jack stands.

2. Using the manufacturers recommended lifting point(s), raise front of vehicle and support with jack stands. **NEVER WORK ON A VEHICLE SUPPORTED ONLY WITH A JACK!**



3. Support sub-frame with jack stands or jack screw in areas shown.



4. Remove (2) front lower control arm bolts (19mm hex) and (2) sub-frame bolts (17mm hex) in area shown.



5. Position the brace as shown and install bolts by hand.



6. Torque all bolts to 76 ft./lbs. (98Nm).



7. Installation is now complete.

8. Double-check complete installation and TEST DRIVE CAREFULLY!

NOTE: DO NOT USE X-BRACE AS A JACKING POINT!