

NEUSPEED®

RACE SERIES COLD AIR EXTENSION KIT – PART #65.02.50

For use with NEUSPEED® P-Flo™ Kit #65.02.65 or 65.10.97

PARTS LIST:

- 1 – COLD AIR RACE EXTENSION PIPE
- 2 – HOSE CLAMPS

- 1 – SILICONE HOSE
- 2 – VINYL CAPS

TOOLS REQUIRED:

- 1 – T25 TORX
- 1 – 10mm SOCKET
- 1 – RATCHET

- 1 – T30 TORX
- 1 – SCREWDRIVER

1. With NEUSPEED P-Flo already installed, remove air filter from end of P-Flo intake pipe.



2. Underneath headlight, remove the outer most bolt (Audi [T30 Torx], VW [10mm hex]) on frame rail. **NOTE:** Headlight has been removed to ease photography.



3. Mount the NEUSPEED cold air extension pipe in this location using original bolt.



4. Install supplied silicone hose in between original P-Flo intake pipe and cold air extension pipe using supplied clamps.



5. Turn front wheels to full right lock position or for better access to front bumper cavity, jack-up vehicle and remove wheel. Use a jack stand to support vehicle before continuing installation. Unscrew lower half front wheel well liner using T25 Torx. There are (6) screws and (1) plastic clip inside the fender and (6) screws underneath.



6. Remove fender liner.



7. Install original P-Flo filter onto cold air extension pipe. **NOTE:** Make sure to double-check tightness of air filter clamp after one week.
8. Reinstall fender liner.
9. Double check complete installation and test drive carefully.

NOTE: The Race Series Cold Air Extension Kit is designed for use in dry weather conditions. Use of this kit in wet weather conditions is at your discretion and in remote circumstances can result in engine damage. If you are driving in wet weather conditions, we recommend that you return the filter to the original position on the P-Flo intake pipe. Vinyl caps are supplied to keep the inside of the cold air extension pipe clean when not in use.



TIP: For quick switching between dry and wet driving conditions, we recommend the purchase of an additional air filter (part #NEU.275). In this instance, simply remove silicone hose and install the additional filter onto original P-Flo air intake pipe. Install a single vinyl cap to cold air extension tube to prevent debris from getting into it.

©Copyright 2005, NEUSPEED® All rights reserved.
Reproduction in whole or in part prohibited.
DOC.65.02.50 Rev. 09.14.06