

NEUSPEED®

P-FLO KIT FOR 2002-UP GOLF IV / JETTA IV VR6 24V

PART # 65.10.74

INSTALLATION INSTRUCTIONS

PARTS LIST:	1 – P-FLO SS AIR BOX	2 – ¼”x20x ⁵ / ₈ ” HEX BOLTS
	1 – K&N AIR FILTER	2 – ¼”x20 NYLOC NUTS
TOOLS REQUIRED:	1 – SCREW DRIVER	1 – 7/16” SOCKET
	1 – 10mm SOCKET	1 – 7/16” WRENCH
	1 – PLIERS	1 – 6” OR LONGER SOCKET EXTENSION

Features of the *NEUSPEED*® Stainless Steel P-Flo air intake system, is that stainless steel reflects heat away from the air filter, and along with its hi-tech looks, it will never rust.

1. Unplug Mass Air Flow (MAF) sensor wire. Squeeze spring clamp that holds the air intake hose to the MAF sensor, and pull hose off MAF.
2. Remove the two screws on back side of air filter housing and lift off top cover. Then remove the two bolts (10mm) located at front and back of lower portion of air filter housing and remove.
3. Remove MAF (two screws) from top cover. Using supplied bolts and nyloc nuts (7/16”), attach the MAF to the engine side of P-Flo bracket with the electrical connector facing toward the rear.
4. Install completed assembly using the stock bolts (10mm) thru mounting tabs at front and rear locations. Re-clamp the air intake hose to the MAF sensor; connect MAF sensor wire into harness.
5. Install K&N filter. Recheck filter clamp for tightness a week later.
6. Carefully double-check complete installation. **TEST DRIVE CAREFULLY!**