

# NEUSPEED®

## REAL CARBON FIBER ENGINE COVER

FITS ALL AUDI A3 2.0T, VW GTI MKV 2.0T, JETTA V 2.0T & PASSAT 2.0T  
WITH NEUSPEED® P-FLO™ PART #65.02.65 OR 65.10.97  
PART # 68.02.65  
INSTALLATION INSTRUCTIONS



**PARTS LIST:** 1 – REAL CARBON FIBER ENGINE COVER

**TOOLS REQUIRED:** 1 – T30 TORX  
1 – VASELINE OR EQUIVALENT

1. With *P-Flo* already installed, pull off (2) of the rubber mounting grommets from underside of original engine cover/air box and reinstall them onto the stand-offs on the intake manifold. Apply a little Vaseline or equivalent grease to the lip and groove of the rubber grommets.
2. At the front of the intake manifold, remove the T30 Torx screw that secures the air temperature sensor to the intake manifold.
3. Install *NEUSPEED* Carbon Fiber Engine Cover aligning billet stand-offs to rubber grommets and push on.
4. Attach front stainless steel strap mount between original T30 Torx screw and air temperature sensor.

**NOTE:** Care should be taken when removing the cover. Before lifting off cover, slight push the cover rearward then gently lift off. Always grease grommets when replacing the carbon fiber cover.